




Xbike

INSTRUCTION MANUAL



Foldable Magnetic Exercise X-Bike
ST-X6



IMPORTANT!

Please read all instructions carefully before using this product.

Retain this manual for future reference.

SAFETY INSTRUCTIONS

Basic precautions should always be followed, including the following safety instructions when using this equipment: Read all instructions before using this equipment.

1. Read all the instructions in this manual and do warm up exercises before using this equipment.
2. Before exercise, in order to avoid injuring the muscle, warm-up exercise of every position of the body is necessary. Refer to Warm Up and Cool Down Routine page. After exercise, relaxation of the body is suggested for cool-down.
3. Please make sure all parts are not damaged and fixed well before use.
This equipment should be placed on a flat surface when using.
Using a mat or other covering material on the ground is recommended.
4. Please wear proper clothes and shoes when using this equipment; do not wear clothes that might catch any part of the equipment.
5. Do not attempt any maintenance or adjustments other than those described in this manual. Should any problems arise, discontinue use and consult an Authorized Service Representative.
6. Do not use the equipment outdoors.
7. This equipment is for household use only.
8. Only one person should be on the equipment while in use.
9. Keep children and pets away from the equipment while in use.
This machine is designed for adults only.
The minimum free space required for safe operation is not less than two meters.
10. If you feel any chest pains, nausea, dizziness, or short of breath, you should stop exercising immediately and consult your physician before continuing.
11. The maximum weight capacity for this product is 120kgs.

WARNING:


Before beginning any exercise program consult your physician. This is especially important for the persons who are over 35 years old or who have pre-existing health problems.

Read all instructions before using any fitness equipment.

CAUTION:


Read all instructions carefully before operating this product.
Retain this Owner's Manual for future reference.

MAIN PARTS




HARDWARE PACKING LIST

A




1. Socket Head Cap Screw x 2
2. Curved Gasket x 2

B




Socket Head Cap Screw x 2

C



Allen Wrench
and Spanner

D





Knob

ASSEMBLY INSTRUCTIONS

1. Install the Ball Pin.

Pull the ball pin out to expand the main frame, and then insert the ball pin back.





2. Install the Front and Rear Stabilizers



Loosen the screws in the stabilizer, and insert them into the corresponding grooves and tighten in each stabilizer.

The stabilizer with wheels attaches to the front frame.

3. Install the Frame and Resistance Adjuster

Place the upper frame onto the main frame, tighten it with the bolts.

Place the resistance adjuster onto the corresponding groove, tighten it with the bolts.



4. Install the Left & Right Pedals Place the upper
Attach the left and right pedals on to their corresponding axles.


5. Install the Back Handlebar and Seat Cushion

a) Loosen the nylon nuts & washers, place the Seat Handlebar back on to the triangle plate & tighten securely.

b) Place the Seat Cushion on to the triangle plate & tighten securely.


6. Install the seat cushion to the bicycle

Install the seat cushion onto the bike and fix it with the height adjustment knob.




7. Install the Handlebar & Control Panel

Place the handlebar onto the corresponding grooves in the main frame, tighten it with bolts and gaskets. Slide the control panel onto the main frame and tighten. Connect the cords into the corresponding slots.



OPERATING INSTRUCTIONS




TENSION ADJUSTMENT

For tension adjustment, simply use the tension adjustment knob (18) found beneath the computer.

To increase tension, turn clockwise (+), to decrease tension, turn anti-clockwise (-). It sets the lowest magnetic force on the level 1
It sets the highest magnetic force on the level 8

HOW TO ADJUST THE SEAT'S HEIGHT:




A. Loose the knob off.

B. Adjust to the required height.

C. Finally tighten the knob

SAFE STORAGE INSTRUCTIONS

Store your X-BIKE in a dry area away from children and high traffic areas. be sure it is secure and cannot fall forward onto small animals or children.





CAUTION:

Don't adjust the height of the seat post over the "STOP" marking shown on the seat post. Or it is dangerous.

HOW TO FOLD THE X-BIKE:

1. Pull out the ball pin into the position.



Folding for Storage

Carefully remove the **Ball Pin**, and slide the **Stabilizer Bars** together to fold the bike up. Re-insert the **Ball Pin** and secure in place.

OPERATION



FUNCTIONS

SCAN	Displays all function TIME→DISTANCE →CALORIES →PULSE→ RPM/SPEED in sequence
RPM	Displays the pedaling Rotation Per Minute. The RPM and SPEED will switch to another display in every 6 seconds after exercise starts
SPEED	Displays the user's exercise speed
TIME	1. You can use joggle wheel to set target time between 0:00 to 99:00 for count down function. 2. It can be set up by the user or accumulated automatically for count up function.
DISTANCE	1. Your can use joggle wheel to set target distance between 0.00 to 99.50 for count down function. 2. It can be set up by the user or accumulated automatically for count up function.
BODY FAT	In STOP mode, press the BODY FAT button to start body fat measurement. During measuring, user has to hold both hands on the handgrip. And the LCD will display “-” “-“” “-“” “-“” for 8 seconds until computer finish measuring. LCD will display BMI, FAT% by turn every 3 seconds.

BUTTONS:

MODE	To confirm all settings
JOGGLE WHEEL - UP	Rotate right (or press it) to select training mode and adjust function value up. Rapidly rotate to increase the value fast
JOGGLE WHEEL - DOWN	Rotate left (or press it) to select training mode and adjust function value down. Rapidly rotate to decrease the value fast
RESET	To clear the set-up value. Press RESET key and hold for 2 seconds to reset all function figures
TOTAL RESET	To power on the console again
RECOVERY	To test heart rate recovery status
BODY FAT	To start or stop body fat testing

1. RECOVERY :

- When the user presses "RECOVERY" button, the RECOVERY function is active. At this time only PULSE and TIME is working, other functions will not be displayed, and the Sensor Input is not available. TIME starts to count down from "0 : 60", Pulse signal will be blinking according user's heart rate BPM. When Time counts down to "0", it will show F1~F6 (F1 is the best, F6 is the worst).
- LCD display as follows: (RECOVERY start condition & end condition).



- If the countdown action to 0:00 is not completed and there is no pulse signal, the countdown action has to be done and shown F6.
- If you press the RECOVERY button prior to count down to 0:00, it will be end and return to the main menu.

2. BATTERY REPLACEMENT

The Monitor uses two AA batteries. Replace the batteries when the display begins to fade or the values become very inaccurate.

To replace the batteries: Remove the battery cover on the back of the Monitor, install new batteries, ensuring the polarity is in the correct direction, and replace battery cover. When the batteries are removed, all data will be cleared to zero.

WARM UP EXERCISES

A successful exercise program consists of a warm-up, aerobic exercise, and a cool-down. Do the entire program at least two and preferably three times a week, resting for a day between workouts. After several months, you can increase your workouts to four or five times per week.

Warming up is an important part of your workout, and should begin every session. It prepares your body for more strenuous exercise by heating up and stretching out your muscles, increasing your circulation and pulse rate, and delivering more oxygen to your muscles. At the end of your workout, repeat these exercises to reduce sore muscle problems. We suggest the following warm-up and cool-down exercises:

Inner thigh stretch


Sit with the soles of your feet together with your knees pointing outward. Pull your feet as close into your groin as possible.


Gently push your knees towards the floor. Hold for 15 counts.



Hamstring stretch

Sit with your right leg extended. Rest the sole of your left foot against your right inner thigh. Stretch toward your toe as far as possible. Hold for 15 counts. Relax and then repeat with left leg extended.






Head roll

Rotate your head to the right for one count, feeling the stretch up the left side of your neck. Next, rotate your head back for one count, stretching your chin to the ceiling and letting your mouth open. Rotate your head to the left for one count, and finally, drop your head to your chest for one count.


Shoulder lift

Lift your right shoulder up toward your ear for one count. Then lift your left shoulder up for one count as you lower your right shoulder.



Calf-Achilles stretch

Lean against a wall with your left leg in front of the right and your arms forward. Keep your right leg straight and the left foot on the floor; then bend the left leg and lean forward by moving your hips toward the wall. Hold, then repeat on the other side for 15 counts.




Toe Touch

Slowly bend forward from your waist, letting your back and shoulders relax as you stretch toward your toes. Reach down as far as you can and hold for 15 counts.



Side Stretch

Open your arms to the side and continue lifting them until they are over your head. Reach your right arm as far upward toward the ceiling as you can for one count. Feel the stretch up your right side. Repeat this action with your left arm.



TROUBLE SHOOTING GUIDE

- 1) Verify that all the bolts and nuts are locked properly and the turning parts should be turned freely without damaged parts.
- 2) Clean the equipment with soap and slightly damp cloth only.
Please do not use any solvent to clean the equipment.

Problem	Potential Cause	Corrections
Base is unstable.	<ol style="list-style-type: none"> 1. Floor is not flat or there is small object under the front or rear stabilizer. 2. The rear stabilizer end caps have not been leveled when adjusting. 	<ol style="list-style-type: none"> 1. Remove the object. 2. Adjust the rear stabilizer end caps.
Handlebar is shaking.	The Bolts are loose.	Tighten the Bolts.
Loud noise from the moving parts.	The interval of the parts is improper tighten.	Open the covers to adjust.
No resistance when riding the bike.	<ol style="list-style-type: none"> 1. The interval of the magnetic resistance increases. 2. Tension control knob is damaged. 3. Belt slips. 4. The bearing set is damaged. 	<ol style="list-style-type: none"> 1. Open the covers to adjust. 2. Change the tension control knob. 3. Open the covers to adjust. 4. Change the bearing set.

DISPOSAL OF OLD ELECTRICAL APPLIANCES:



The European directive 2002/96/EC on Waste Electrical and Electronic Equipment (WEEE), requires that old household electrical appliances must not be disposed of in the normal unsorted municipal waste stream. Old appliances must be collected separately in order to optimize the recovery and recycling of the materials that they contain and reduce the impact on

human health and the environment.

The crossed out “wheeled bin” symbol on the product reminds you of your obligation, that when you dispose of the appliance, it must be separately collected. Consumers should contact their local authority or retailer for information concerning the correct disposal of their old appliance.

LIMITED WARRANTY:

Limited Warranty applies to purchases made from authorized retailers of **TurboTronic®**. **TurboTronic®** Warranty coverage applies to the original owner and to the original product only and is not transferable. **TurboTronic®** warrants that the unit shall be free from defects in material and in workmanship. The Limited Warranty applies only when the unit is used under normal household conditions and maintained according to the

requirements stated in the Owner's Guide, subject to the following conditions and exclusions:

ANY WARRANTY OR AFTER PURCHASE SERVICE, SHOULD BE WITH THE THIRD-PARTY COMPANY, FROM WHICH YOU PURCHASED THE PRODUCT. TURBOTRONIC® PROVIDES THE WARRANTY ONLY TO OUR THIRD-PARTY SUPPLIERS. SINCE THIS PRODUCT WAS NOT PURCHASED DIRECTLY FROM TURBOTRONIC® BUT VIA ONE OF OUR THIRD-PARTY SUPPLIERS, ANY ISSUE AFTER THE PURCHASE, CUSTOMER SERVICE OR RECEIVING THE WARRANTY, SHOULD BE ONLY / DIRECTLY HANDLED VIA THE THIRD-PARTY SUPPLIER FROM WHICH YOU PURCHASED THE PRODUCT.

What is covered by this warranty?

1. The original unit and/or non-wearing parts deemed defective will be repaired or replaced, at **TurboTronic®** sole discretion.
2. **TurboTronic®** reserves the right to replace the unit with one of equal or greater value.

What is not covered by this warranty?

1. Normal wear and tear of wearing parts (such as blending vessels, lids, cups, blades, blender bases, removable pots, racks, pans, etc.), which require regular maintenance and/or replacement to ensure the proper functioning of your unit, are not covered by this warranty.
2. Any unit that has been tampered with or used for commercial purposes.
3. Damage caused by misuse, abuse, negligent handling, failure to perform required maintenance (e.g., failure to keep the well of the motor base clear of food spills and other debris), or damage due to mishandling in transit.
4. Consequential and incidental damages.
5. Defects caused by repair persons not authorized by **TurboTronic®**. These defects include damage caused in the process of shipping, alteration, or repair of the **TurboTronic®** product (or any of its parts) when the repair is performed by a repair person not authorized by **TurboTronic®**.
6. Products purchased, used, or operated outside Europe.

Illustrations may differ from actual product.

We constantly strive to improve our products, therefore the specifications contained herein are subject to change without notice.

TurboTronic®, **SportTronic®** and **Z-Line®**
are registered trademarks of **Z-GLOBAL B.V.B.A®**.